

Selecting a Switch Box

Paul Nuttall Director of SEMERC

Which type of Computer are you using PC or Mac?

Mac

Recommend USB Switch Box (Crick) up to 4 switches works with all USB equipped Macs



PC

How Many Switches do you want to connect?

12 switches JoyBox



5 switches Don Johnson Switch Interface pro

4 switches USB Switch Box (Crick)



2/3 switches Mouser3 or Mouser 4

2 switches USB JoyCable, Serial Switch Adaptor





PC Laptops

May not have serial port and can't guarantee power level for serial boxes.

Recommend: JoyCable (USB switch adaptor) up to 2 switches \$109.00

JoyBox up to 12 switches

USB Switch Box Crick 4 switches

Mouser 4 2/3 switches

PC Desktops any Windows operating system

Normally have one or two serial ports

Recommend:

Serial Switch Adaptor 2 switches

SEMERC Serial Switch Box 2 switches

Mouser 3 2/3 switches

Don Johnson Switch Interface Pro 5 switches

If running Windows 98 or above e.g. Windows XP, 2000 or 98

Earlier version of window do not recognise USB devices

Recommend:

Joy Cable 2 switches

JoyBox 12 switches

USB switch box (Crick) 4 switches

Mouser 4 2/3 switches

USB port



PS2/Keyboard port



Serial port

